

FIG. 1

1/3

100




FIG. 2

Operation mode \ Input medium		Recording/reproduction medium	Reproduction-only medium			
			DVD-Recording	DVD-Video	V-CD	CD-A
141	Stop mode	144	A1	A1	A1	A1
				Mute	Mute	Mute
142	Reproduction mode		A1	B1	C1	D1
143	Recording mode		A1	—	—	—

121 122A 122B 123

145

FIG. 3




FIG. 4




FIG. 5

